



## **AC Powered TS1000 Installation Pictures**

**(Core Drill and Saw Cut)**

**City of Manteca, CA**

**11/07**

# AC Powered TS1000 Installation Pictures



1. Fixture layout



2. Core Drill



3. Saw Cut



4. Drainage



5. Mounting Jig Setup



6. Base Can Alignment

## AC Powered TS1000 Installation Pictures



7. Base Can in Concrete



8. Plywood Protective Cover



9. Fixtures Placed In Base Cans